$\begin{array}{c} \textbf{Project Based Engineering Instrumentation With} \\ \textbf{CircuitPython} \end{array}$

A Brief Textbook Presented to the Student Body of the University of South Alabama

Last Update: May 30, 2022 Copyright © Carlos José Montalvo

Manuscript Changes

- 1. Original tutorials in Google Docs created
- 2. Tutorials moved to LaTeX on this Github
- 3. December 21st, 2021 Updated links for manuscript and hardware
- 4. Tutorials purchased by Tangibles that Teach and moved to url https://tangibles-that-teach.gitbook.io/instrumentation-lab-manual/-MbMx70LQzRmEG_hS7Ld/
- 5. May 31st, 2022 Tangibles that teach went out of business and chapters moved here

Changes Needed

1. All chapters from TTT need to be moved here

Acknowledgements

The author, Dr. Carlos Montalvo would like to acknowledge a few key members who made this textbook possible. First and foremost I would like to thank Adafruit for their entire ecosystem of electronics, tutorials, blogs and forums. Much of what I have learned here to teach Instrumentation was from Adafruit and the Adafruit Learn system and specifically people like Lady Ada and John Park who have helped shape CircuitPython and the Circuit-Playground Express to what it is today. I would also like to thank Dr. Saami Yazdani for creating the blueprint for Instrumentation at my university by creating a laboratory environment for an otherwise totally theoretical course. His course was the foundation for this textbook and for that I thank him for showing the way. Id like to also thank and acknowledge Tangibles that Teach for giving me the opportunity to morph this loose set of projects into a textbook that can be used for multiple universities and classrooms and of course help students learn and acquire knowledge through creating.

About this textbook

This textbook has been designed with the student and faculty member in mind. First, this textbook goes hand in hand with Engineering Instrumentation taught at the undergraduate level at many universities. The course begins with simple plotting and moves into data analysis, calibration and more complex instrumentation techniques such as active filtering and aliasing. This course is designed to get students away from their pen and paper and build something that blinks and moves as well as learn to process real data that they themselves acquire. There is no theory in these projects. It is all applied using the project based learning method. Students will be tasked with downloading code, building circuitry, taking data all from the ground up. By the end of this course students will be well versed in the desktop version of Python while also the variant CircuitPython designed specifically for microelectronics from Adafruit. After this course students will be able to understand Instrumentation at the fundamental level as well as generate code that can be used in future projects and research to take and analyze data. Python is such a broad and useful language that it will be very beneficial for any undergraduate student to learn this language. To the professors using this textbook, 1 credit hour labs are often hard to work into a curriculum and live demonstrations in the classroom cost time and money that take away from other faculty duties. Ive created this kit and textbook to be completely stand-alone. Students simply need to purchase the required materials and follow along with the lessons. These lessons can be picked apart and taught sequentially or individually on a schedule suited to the learning speed of the course. I hope whomever reads and learns from this textbook will walk away with an excitement to tinker, code and build future projects using microelectronics and programming.


Contents

1	Pur	chase Instrumentation Equipment	5
	1.1	Quick Links	5
	1.2	Turning in this assignment	5
	1.3	Purchase Items Yourself	6
	1.4	Bill of Materials (per 4 students)	6
	1.5	Detailed Parts List	6
2	CIR	RCUIT PLAYGROUND, CIRCUITPYTHON, and PYTHON	8
	2.1	Parts List	8
	2.2	Which IDE?	8
		2.2.1 Thonny	8
		2.2.2 Spyder	8
	2.3	Other Options	6
	2.4	Setting up your IDE	Ć
	2.5	Scripting	10
	2.6	Turning in this Assignment	13

1 Purchase Instrumentation Equipment

In this class youre going to build some circuits that will enhance your learning experience. Rather than just solving problems by hand youre going to take and analyze data. Over the summer of 2020, I wrote a textbook with Tangibles that Teach and they have graciously bundled all components together. The price is \$50 plus shipping so its about the same price as below but youll probably save on shipping from multiple vendors and everything is all in one place which is nice. There is an accompanying textbook that can be downloaded as well.

When you get your kit familiarize yourself with all of the components. I created an unboxing video on Youtube for you to take a look. Below is also a photo of all the components.



1.1 Quick Links

- 1. Kit
- 2. Document
- 3. Unboxing Video

1.2 Turning in this assignment

- 1. Upload a receipt of ALL of your purchases 50%
- 2. Put your name and the names of your group members. If working alone, tell me you are planning on working alone in the PDF you upload. In times of COVID, everyone is working alone 50%

ONLY READ BELOW IF YOU DONT WANT TO BUY THE KIT ABOVE

1.3 Purchase Items Yourself

The bill of materials listed below is designed for 2 or 4 students to work together and share pieces. This kit is not optimized for 3 students. If you are a remote/online student or you just prefer to work alone then you have the option of purchasing everything yourself. The cost per student in a group of 4 and 2 is listed as well as the cost if working alone. Youll find that even with the optional equipment, the cost of working alone is still less than the price of a standard college textbook. Note that if you are working alone, be sure to only purchase 1 of each item. If working in pairs you also have the option of purchasing one of each item. Finally, if you own some of these components you may wish to simply purchase each item separately. A detailed parts breakdown is shown after the rubric.

1.4 Bill of Materials (per 4 students)

Item (ONLY IF YOU DONT WANT THE KIT ABOVE)	Quantity	Total Cost
Circuit Playground Express (CPX)	2	\$50
Servo	2	\$10
USB Cable	2	\$6
Electronics Kit (Photocells, Resistors, Trimpot)	1	\$13
Alligator Clips	1	\$4
Total		\$83
Cost per student in a group of 4		\$21
Cost per student in a group of 2		\$25
Cost if working alone		\$50
Optional Equipment		
External Power Supply	2	\$6
AA Batteries	2	\$6
Analog Pitot Probe	1	\$31
Rate Gyro (LSM6D3SS)	1	\$10
Total with Optional Equipment		\$136
Cost per student in a group of 4		\$34
Cost per student in a group of 2		\$50
Cost if working alone		\$97

1.5 Detailed Parts List

If you want to just purchase each component separately you can, just make sure you have all of the parts below.

- 1. Circuit Playground Express (CPX)
- 2. Servo
- 3. Alligator Clips
- 4. USB Cable
- 5. Push Button
- 6. Breadboard
- 7. Photocell
- 8. Resistors (10 kOhm, 330 Ohm, 1 kOhm)
- 9. LED (x3 in case you fry one)
- 10. Male to Male Wires (x2)
- 11. Potentiometer

You can also purchase some optional equipment as shown below.

- Rate Gyro (LSM6D3SS)
 Male to Male Wires (x2)
 Alligator Clips (x1)
 Double Sided Tape
 Analog Pitot Probe

2 CIRCUIT PLAYGROUND, CIRCUITPYTHON, and PYTHON

As you learn Instrumentation throughout the semester, you will be tasked with creating computer programs on the Circuit Playground Express (CPX). The CPX itself has its own RAM, CPU, HDD and many sensors. Your CPX is kind of like a mini computer! You can plug the CPX into your computer via USB and access the hard drive (HDD) from your own computer. When you program on the CPX you need to write programs on the CPX itself so that the mini computer can run the program you wrote. The CPX knows how to read multiple different languages but in this class we are going to write everything in the Python language which has been ported to the CPX and called CircuitPython. Since we have to write everything in CircuitPython we need to first learn how to program some things in Python. You can easily download Python by itself but its nice to get whats called an Integrated Development Environment (IDE). This way you can practice writing Python code on your computer while you wait for your purchases to arrive in the mail.

2.1 Parts List


Laptop + internet connectivity

2.2 Which IDE?

So which IDE can you download and which is recommended? I recommend two IDEs. They are listed below. I recommend getting either one. If you just Google Python download you will find a humongous list of editors (Scratch, Anaconda, Canopy, Eclipse, PyDev, etc). Its easy to get lost when searching for something so broad. Youve been warned.


2.2.1 Thonny

Thonny - https://thonny.org/ - Youtube video on how to install



2.2.2 Spyder

Spyder - https://www.spyder-ide.org/ - Youtube video on how to install




2.3 Other Options

It is possible to use Google Colab if you want to collaborate on Python projects or even get apps for your phone (Pydroid or Pythonista depending on Android or iPhone). You'll need to download 32 bit or 64 bit but which one? Well you need to figure out how many bits your computer has. This is a great thing to Google. Type the following: "do I have a 32 bit or 64 bit computer" into Google. Im willing to bet you have a 64 bit computer but you may as well check. Well learn about the difference between 32 and 64 bit computers when we get to the projects on Binary.

2.4 Setting up your IDE

Once you have Thonny or Spyder installed you need to install numpy and matplotlib which are modules within Python that allow us to do some extra things like numerical computation with Python (numpy) and Matlab style Plotting libraries (matplotlib). I explain how to install modules in my Youtube videos above; however, you need to head over to Tools; Manage Packages in Thonny. You can see in the image below I already have version 3.1.2 but I can upgrade to 3.2.2




If numpy or matplotlib is not already included in Spyder then you need to type the following into the Python Console in the lower right hand corner of Spyder which is called the IPython console.

!pip install matplotlib

If that doesn't work try

!pip3 install matplotlib

You can see in the output example below that I already have matplotlib installed as it says requirement already satisfied. Assuming you have a valid internet connection it will install the necessary module.



2.5 Scripting

Once you have numpy and matplotlib its time to make a plot. I have a pretty comprehensive youtube video on how to plot in matplotlib but if you prefer text I will walk through a simple example.

```
import numpy as np
import matplotlib.pyplot as plt

x = np.linspace(0,2*np.pi,1000)
y = np.sin(x)

plt.plot(x,y)

plt.show()
```

The code above will plot a sine wave from 0 to 2pi. The two lines at the top are importing the numpy and matplotlib modules you installed earlier. When they are imported we give them shorter names so its easier to reference them so numpy will now be called np and matplotlib.pyplot will be called plt. The next two lines then create a vector x from 0 to 2pi using 1000 data points. The next line then uses the sine function to create the vector y. Finally x and y are plotted and the figure is instructed to pop up on your screen using the show() function. Now that you somewhat understand some of this Id like you to plot the following function:

$$T(t) = 60(1 - e^{-5t}) + 30 (1)$$

Plot the function from 0 to 10 seconds and label the x axis Time (sec) and the y-axis Temperature (F). Add a grid as well. There are some things that I have not explicitly shown you how to do. The reason why is because I want to teach you how to fish for information.

The first thing I recommend trying is to type in the commands in the IPython console or the Shell. Type the first two commands below which will show you every single function that numpy has available to you.

 $import \ numpy \ as \ np \ dir(np)$

>>> import numpy as np

>>> dir(np)

['ALLOW_THREADS', 'AxisError', 'BUFSIZE', 'CLIP', 'ComplexWarning', 'DataSource', 'ERR_CALL', 'ERR_ DEFAULT', 'ERR_IGNORE', 'ERR_LOG', 'ERR_PRINT', 'ERR_RAISE', 'ERR_WARN', 'FLOATING_POINT_SUPP ORT', 'FPE_DIVIDEBYZERO', 'FPE_INVALID', 'FPE_OVERFLOW', 'FPE_UNDERFLOW', 'False_', 'Inf', 'Infinit y', 'MAXDIMS', 'MAY_SHARE_BOUNDS', 'MAY_SHARE_EXACT', 'MachAr', 'ModuleDeprecationWarning', ' NAN', 'NINF', 'NZERO', 'NaN', 'PINF', 'PZERO', 'RAISE', 'RankWarning', 'SHIFT_DIVIDEBYZERO', 'SHIFT_I NVALID', 'SHIFT_OVERFLOW', 'SHIFT_UNDERFLOW', 'ScalarType', 'Tester', 'TooHardError', 'True_', 'UFU NC BUFSIZE DEFAULT', 'UFUNC PYVALS NAME', 'VisibleDeprecationWarning', 'WRAP', 'NoValue', 'UFUNC PYVALS NAME', 'UFUNC PYVALS NAME', 'NOVALUE', 'UFUNC PYVALS NAME', 'NOVALUE', 'UFUNC PYVALS NAME', 'UFUNC PYV FUNC_API', '__NUMPY_SETUP__', '__all__', '__builtins__', '__cached__', '__config__', '__doc__', '__file _', '__git_revision__', '__loader__', '__name__', '__package__', '__path__', '__spec__', '__version__', '_add_newdoc_ufunc', '_distributor_init', '_globals', '_mat', '_pytesttester', 'abs', 'absolute', 'absolute import', 'add', 'add docstring', 'add newdoc', 'add newdoc ufunc', 'alen', 'all', 'allclose', 'alltrue', ' amax', 'amin', 'angle', 'any', 'append', 'apply_along_axis', 'apply_over_axes', 'arange', 'arccos', 'arcc osh', 'arcsin', 'arcsinh', 'arctan', 'arctan2', 'arctanh', 'argmax', 'argmin', 'argpartition', 'argsort', 'argw here', 'around', 'array', 'array2string', 'array_equal', 'array_equiv', 'array_repr', 'array_split', 'array_str', asanyarray', 'asarray', 'asarray_chkfinite', 'ascontiguousarray', 'asfarray', 'asfortranarray', 'asmatrix', ' asscalar', 'atleast_1d', 'atleast_2d', 'atleast_3d', 'average', 'bartlett', 'base_repr', 'binary_repr', 'binco unt', 'bitwise_and', 'bitwise_not', 'bitwise_or', 'bitwise_xor', 'blackman', 'block', 'bmat', 'bool', 'bool8', 'bool_', 'broadcast', 'broadcast_arrays', 'broadcast_to', 'busday_count', 'busday_offset', 'busdaycalen dar', 'byte', 'byte_bounds', 'bytesO', 'bytes_', 'c_', 'can_cast', 'cast', 'cbrt', 'cdouble', 'ceil', 'cfloat', 'c har', 'character', 'chararray', 'choose', 'clip', 'clongdouble', 'clongfloat', 'column_stack', 'common_typ

I included a photo of the output from the dir function. Youll notice there are a ton of functions in numpy. Every function in Python has a

__doc__

function. Thats two underscores followed by doc and then another two underscores. If youre ever curious about what a particular function does you can just run the command below again in the IPython console or Shell. In this example Im looking at what arctan2 does.

print(np.arctan2.__doc__)

```
>>> print(np.arctan2.__doc__)
 arctan2(x1, x2, /, out=None, *, where=True, casting='same_kind', order='K', dtype=None,
 subok=True[, signature, extobj])
 Element-wise arc tangent of ``x1/x2`` choosing the quadrant correctly.
 The quadrant (i.e., branch) is chosen so that ``arctan2(x1, x2)`` is
 the signed angle in radians between the ray ending at the origin and
 passing through the point (1,0), and the ray ending at the origin and
 passing through the point ('x2', 'x1'). (Note the role reversal: the
 "`y`-coordinate" is the first function parameter, the "`x`-coordinate"
 is the second.) By IEEE convention, this function is defined for
 x^2 = +/-0 and for either or both of x^1 and x^2 = +/-inf (see
 Notes for specific values).
 This function is not defined for complex-valued arguments; for the
 so-called argument of complex values, use `angle`.
 Parameters
 x1 : array_like, real-valued
     `y`-coordinates.
 x2 : array_like, real-valued
      `x`-coordinates. If ``x1.shape != x2.shape``, they must be broadcastable to a commo
 n shape (which becomes the shape of the output).
 out : ndarray, None, or tuple of ndarray and None, optional
```

Youll see that arctan2 takes 2 input arguments x1 and x2. I didnt include the entire output but if you continue to scroll through the output it will even include examples on how to use the function.

Another way to learn certain functions is by visiting the appropriate documentation. The Numpy Docs website for example has all the documentation you need for Numpy. Navigating that website you can find the same documentation for arctan 2.

As a last resort you can always Google how to compute the inverse tangent 2 function in Python. Note though that there is so much content out there on Google that you could easily get lost. Still, there also so much information that the answers are out there for just about anything.

So you have three methods for finding out how to program in python. The dir and __doc__ functions in Python, using the appropriate documentation online and of course Google. Im lumping Youtube in with Google which is also another way to learn information although when I want to find information quickly I just use the documentation. Its the best in my opinion.

2.6 Turning in this Assignment

Upload a PDF with all of the photos below included. My recommendation is for you to create a Word document and insert all the photos into the document. Then export the Word document to a PDF and then upload the PDF.

- 1. Screenshot of your Python IDE 25%
- 2. Take a selfie of you watching one of my python youtube videos and upload that photo 25%
- 3. Screenshot your code of the temperature plot above even if it doesn't work 25%
- 4. If you got the code to work, hit the Floppy Disk button (SAVE) when your figure pops up and include that in your upload 25%